



INSTRUCTIONS

Hot Dog Roller Grill

WARNING: DO NOT USE AN EXTENSION CORD! Be certain no other equipment is operating from the same outlet. Failure to do so will reduce the unit's output and performance.

- Place the hot dogs on the rollers.
- Turn the heat to the designated temperature. The left knob controls the heat of one set of five (5) rollers and the right controls the other set of five (5) rollers.
- For low capacity, set the low using one or both sets of rollers. For high capacity, set on high or medium using both sets of rollers.