



# INSTRUCTIONS

## Propane Stove

**NOTE:** It is recommended that you use a long grill lighter to avoid contact with your hands. Always use in a well-ventilated area - **OUTDOOR USE ONLY.**

- Install propane tank.
- Be sure all the knobs on the stove are in the OFF position.

**IMPORTANT NOTE:** OPEN THE PROPANE VALVE VERY SLOWLY. Failure to open the propane valve slowly will result in a freeze of the regulator and a blow out of the gasket.

- Open oven door and remove the bottom panel to light the pilot.
- Push the **RED** button near the bottom/front and hold while lighting the pilot (inside the oven).
- Once the pilot is lit, continue to hold in the **RED** button for approximately 30-40 seconds.
- Release the button, if the pilot did not light, repeat steps 5 and 6.
- With the pilot lit, replace the bottom panel and close the oven door.
- Proceed to light the center of each burner.
- The stove will then be ready to use. Adjust the flames to the desired heat for cooking.