



INSTRUCTIONS

Refrigerator

WARNING: DO NOT USE AN EXTENSION CORD! Plug the refrigerator into a direct outlet by itself. Failure to do so will weaken effectiveness of the refrigerator or blow the fuse.

NOTE: The set point should be between 35 and 40 degrees.

- Temperature control knob is located on the right hand side of the fan.