

PROPANE GRILL

NOTE: THIS GRILL IS FOR OUTDOOR USE ONLY

OPERATING

1. Prior to opening main cylinder valve, and lighting grill, place all control knobs in the "CLOSED" position. (turned to the left)
2. Open main cylinder valve. Hold a lit butane gun next to a burner and turn the burner control knob "OPEN". Burner will ignite instantly. The other burners will turn on by simply turning the knobs.
3. Once lit, adjust for proper temperature. When finished cooking turn all knobs to "CLOSED" position. (turn left) Close main cylinder valve and disconnect propane cylinder.

CLEANING

1. Clean grates with non-metallic pad (Scotch-Brite) while grates are still hot.

NOTE: Do not use a wire brush on stainless steel grates.

2. Cast Iron Grates must be protected from moisture and stored with a coating of vegetable oil to prevent rusting.

SAFETY

1. Never store propane cylinders indoors.
2. Keep main cylinder valve securely when not in use.

NOTE: Propane tank valves are designed to work completely open and/or completely closed. Never just crack the valve.

3. Always position the LP cylinder so that the connection between the valves and the regulator will not cause sharp bends in the hose.